


# Astoria™

# Firestyles for Life



- Horizontal Or Vertical Vent
- Freestanding Stove
- Mobile Home Approved
- Class A Chimney Retrofit
- Hearth Stove into Existing Masonry Chimney , Masonry Fireplace, or Z.C. Fireplace

Tested and Listed by



Omni-Test Laboratories, Inc. Portland, Oregon Report # 028-S-42-2 ASTM E1509-2004

- Please read this entire manual before installation and use of this pellet fuelburning room heater. Failure to follow these instructions could result in property damage, bodily injury, or even death.
- -- Contact local building or fire officials about restrictions and installation inspection requirements in your area.
- -- Save these instructions.

**Installer**: After installation give this manual to the home-owner and

explain operation of this stove.

\$10.00 © Copyright 2008, T.I. Part # 100-01154



4800 Harbour Pointe Blvd. SW Mukilteo, WA 98275

#### Introduction

We welcome you as a new owner of an Astoria pellet heater. In purchasing an Astoria you have joined the growing ranks of concerned individuals whose selection of an energy system reflects both a concern for the environment and aesthetics. The Astoria is one of the finest home heaters the world over. This manual will explain the installation, operation, and maintenance of this pellet-burning heater. Please familiarize yourself with the Owner's Manual before operating your heater and save the manual for future reference. Included are helpful hints and suggestions which will make the installation and operation of your new heater an easier and more enjoyable experience. We offer our continual support and guidance to help you achieve the maximum benefit and enjoyment from your heater.

#### Important Information

No other Astoria heater has the same serial number as yours. The serial number is on the safety label on the back of the appliance.

This serial number will be needed in case you require service of any type.

Model:	Astoria PS
Serial Number:	
Purchase Date:	
Purchased From:	

Mail your Warranty Card Today, and Save Your Bill of Sale.

To receive full warranty coverage, you will need to show evidence of the date you purchased your heater. Do not mail your Bill of Sale to us.


We suggest that you attach your Bill of Sale to this page so that you will have all the information you need in one place should the need for service or information occur.



We suggest that our pellet hearth products be installed and serviced by professionals who are certified in the U.S. by the National Fireplace Institute® (NFI) as NFI Pellet Specialists or who are certified in Canada by Wood Energy Technical Training (WETT).

<u>Introduction</u>
Introduction2
Important Information2
Safety Precautions
Safety Precautions4
<u>Specifications</u>
Heating Specifications6
Dimensions6
Electrical Specifications6
Fuel6
EPA Compliance6
<u>Installation</u>
Before You Begin7
Packing List7
Installation Options7
Planning The Installation7
Stove Placement7
Floor Protection Requirements7
Clearances - Straight Installation8
Clearances - Corner Installation8
Venting the Pellet Stove9
Maximum Venting Distance9
Pellet Vent Type10
Installing the Pellet Vent10
Pellet Vent Termination10
Mobile Home Requirements11
Outside Air (used for combustion)11
Alcove Installation Requirements12
Baffle Installation12
Door Seal Verification12
Restrictor Adjustment12
Thermostat Installation13
Installation Example: Direct "Through-the-wall" Installation14
Installation Example: Interior Vertical Installation15
Installation Example: Class A Chimney Retrofit16
Installation Example: Masonry Fireplace Hearth Stove17
Installation Example: Zero-Clearance (Metal) Fireplace Hearth Stove 18
Installation Example: Freestanding Masonry Chimney19
<u>Operation</u>
Safety Notice20
Location of Controls20
Starting the Heater for the First Time20
Loading Pellets21
The Two Modes of Operation21

Manual Mode Auto Mode Restrictor Adjustment Restrictor Adjustment Adjusting the Fan Speed Start-Up Sequence "AUGER ON" Light "MAINTENANCE REQUIRED" Light	23 24 24 25 25 25 26
Restrictor Adjustment Restrictor Adjustment Adjusting the Fan Speed Start-Up Sequence. "AUGER ON" Light.	24 24 25 25 25 26
Restrictor Adjustment	24 25 25 25 26
Adjusting the Fan SpeedStart-Up Sequence"  "AUGER ON" Light	24 25 25 26 26
Start-Up Sequence"  "AUGER ON" Light	25 25 26 26
"AUGER ON" Light	25 25 26
•	25 26 26
"MAINTENIANCE DECLUDED" Light	26 26
MAINTENANCE REQUIRED LIGHT	26
"MANUAL AUGER" Button	
Power Outages	26
Using a Pellet/Corn Mix with This Heater	
<u>Maintenance</u>	
Daily Maintenance (whenever using the stove)	27
Inspect the Burn	27
Make Sure Pellets are Not Piling Up	27
Check Firepot for Clinkers	28
Cleaning the Firepot	28
Door Opening	29
Weekly Maintenance (or every 5 bags of pellets)	30
Flyash Removal	30
Clean the Hopper	
Clean the Heat Exchange Tubes	30
Clean the Baffles	
Sweep Ash Into Ashpan	
Check Ashpan, Dispose if necessary	
Clean the Glass	33
Yearly Maintenance (or every ton)	34
Clean the Vertical Exhaust Duct	34
Clean the Exhaust Blower	
Clean the Vent	
Door Seal	36
Normal Operating Sounds	
Normal Operating Sounds	39
<u>Safety Label</u>	
Safety Label	40
Warrant <u>y</u>	
Warranty	41
·	
<u>Index</u>	
Index	42



 Do not operate the heater if you smell smoke coming from the heater. Turn the MODE switch to "OFF", monitor your heater, and call your dealer.



 Contact your local building officials to obtain a permit and information on any installation restrictions or inspection requirements in your area. Notify your insurance company of this heater as well.



· Never use gasoline, gasoline-type lantern fuel, kerosene, charcoal lighter fluid, or similar liquids to start or 'freshen up' a fire in this heater. Keep all such liquids well away from the heater while it is in use.



The exhaust system **must** be completely airtight and properly installed. The pellet vent joints must be sealed with RTV 500° F. (260° C.) silicone sealant.



Do not unplug the heater if you suspect a malfunction. Turn the MODE SWITCH to "OFF" and periodically inspect the heater.



This unit must be properly installed to prevent the possibility of a house fire. The instructions must be strictly adhered to. Do not use makeshift methods or compromise in the installation.



· Never try to repair or replace any part of the heater unless instructions are given in this manual. All other work should be done by a trained technician.




 Your heater requires periodic maintenance and cleaning (see "Maintaining Your Heater"). Failure to maintain your heater may lead to smoke spillage in your home.



 The viewing door and ashpan must be closed and latched during operation.

Never block free airflow

the unit.




Allow the heater to cool before carrying out any maintenance or cleaning. Ashes must be disposed in a metal container with a tight lid and placed on a non-combustible surface well away from the home or structure.



 Do not operate the heater if the flame becomes dark & sooty of if the firepot overfills with pellets. Turn the MODE SWITCH to "OFF" and periodically inspect the heater (see "Running Your Heater").



This heater is designed and approved for pelletized wood fuel or a mixture up to 50% corn, 50% pellets. See page 25 for details on using a corn pellet mix.



 The heater will not operate during a power outage. If a power outage does occur, check the heater for smoke spillage and open a window if any smoke spills into the room.



 This heater must be connected to a standard 115 V., 60 Hz grounded electrical outlet. Do not use an adapter plug or sever the grounding plug. Do not route the electrical cord underneath, in front of, or over the heater.



 Keep foreign objects out of the hopper.



 When installed in a mobile home, the heater must be bolted to the floor, have outside air, and NOT BE INSTALLED IN THE BEDROOM (Per H.U.D. requirements). Check with local building officials.



 Disconnect the power cord before performing any maintenance.

#### NOTE:

Turning the Mode Switch to "OFF" does not disconnect all power to the heater.



 The exhaust system should be checked twice a year minimum for any build-up of soot or creosote.



 Do not throw this manual away. This manual has important operating and maintenance instructions that you will need at a later time. Always follow the instructions in this manual.



 Do not touch the hot surfaces of the heater. Educate all children of the danger of a hightemperature heater. Young children should be supervised when they are in the same room as the heater.



 Do not place clothing or other flammable items on or near the heater.
 Because this heater can be controlled by a thermostat there is a possibility of the heater turning on and igniting any items placed on or near it.




 Travis Industries, Inc. grants no warranty, implied or stated, for the installation or maintenance of your heater, and assumes no responsibility of any consequential damage(s).

#### Heating Specifications

- \* Heating capacity will vary depending on the home's floor plan, degree of insulation, and the outside temperature. It is also affected by the fuel size, quality, and moisture level.
- \*\* Small pellets will increase or decrease the stated burn rates and burn times. Differences of plus or minus 20% depending on fuel quality may occur.

#### **Dimensions**



#### **Electrical Specifications**

#### Fuel

• This heater is designed and approved for pelletized wood fuel or a mixture up to 50% corn, 50% pellets. See page 25 for details on using a corn pellet mix.

#### **EPA** Compliance

This heater has been tested exempt from EPA Phase II Requirements by OMNI-Test Laboratories, Inc.

#### Before You Begin

READ THIS ENTIRE MANUAL BEFORE YOU INSTALL AND USE THIS HEATER. FAILURE TO FOLLOW THE INSTRUCTIONS MAY RESULT IN PROPERTY DAMAGE, BODILY INJURY, OR EVEN DEATH.

Check with local building officials for any permits required for installation of this pellet heater and notify your insurance company before proceeding with installation.

#### Packing List

Thermostat & Wire
 Scraper Rod Tool
 Brush
 Spare Fuses

#### Installation Options

- Residential or Mobile Home (see the section "Mobile Home Requirements")
- Alcove Compatible (see the section "Alcove Installation")
- Horizontal or Vertical Vent
- Outside Air Compatible
- Vent with L-Vent, L-Vent Fireplace Liner, or Type A Chimney (with adapter)

#### Planning The Installation

HINT: Have an authorized Travis Industries dealer install this heater. If you install the heater yourself, have your dealer review your installation plans.

HINT: Sketch out a detailed plan of the installation including dimensions. Then verify the

dimensions with the requirements listed in this manual.

HINT: When determining the location of the stove, locate the wall studs (for horizontal penetrations) and ceiling trusses (for vertical penetrations). You may wish to adjust the stove position slightly to ensure the vent does not intersect with a framing member.

HINT: Place the heater outside and load 10 pounds of pellets inside the hopper. Plug the heater in and let it run on HIGH until the pellets run out. This will cure the paint and burn

off any oil on the steel, eliminating any smell inside the home.

#### Stove Placement

- Stove must be placed so that no combustibles are within, or can swing within (e.g. drapes, doors), 36" of the front of the heater.
- If the stove is placed in a location where the ceiling height is less than 7', it must follow the requirements in the section "Alcove Installation Requirements".


HINT: REDUCING CLEARANCES - Clearances may be reduced by methods specified in NFPA 211, listed wall shields, pipe shields, or other means approved by local building or fire officials.

Heater and floor protection must be installed on a level, secure floor.


#### Floor Protection Requirements

- The heater must be installed on a non-combustible floor protector extending the full width and depth of the heater and extending 6" in front (minimum 27-3/4" wide by 31" deep) (minimum .018" thick 26 gauge) .
- Must extend under and 2" to each side and rear of a "Tee" (if used).

#### Clearances - Straight Installation



#### Clearances - Corner Installation



- \* Install vent at clearance specified by the vent manufacturer.

  NOTE: If interior vertical vent is used, the stove to backwall dimension is determined by the vent being used. This dimension will vary depending on the brand of pellet vent used. To determine the distance from the backwall to the stove, connect the "Tee" and add the vent clearance.
- \*\* The floor protection must extend 2" or to the wall (whichever is less) all vent clearances must be met.

#### Venting the Pellet Stove

- INSTALL VENT AT CLEARANCES SPECIFIED BY THE VENT MANUFACTURER.
- DO NOT CONNECT THE PELLET VENT TO A VENT SERVING ANY OTHER APPLIANCE OR STOVE.
- DO NOT INSTALL A FLUE DAMPER IN THE EXHAUST VENTING SYSTEM OF THIS UNIT.
- USE AN APPROVED WALL THIMBLE WHEN PASSING THE VENT THROUGH WALLS AND A CEILING SUPPORT/FIRE STOP SPACER WHEN PASSING THE VENT THROUGH CEILINGS (MAKE SURE TO MAINTAIN CLEARANCE TO ANY COMBUSTIBLES).
- No more than one tee and 180° of elbows (one tee with two 90° elbows, one tee with one 90° and two 45° elbows, etc.).

#### 33 Feet (max.) **Maximum Venting Distance** \_\_ 30 Feet Vent must have a support The vent height and run bracket every 5' of pellet vent 25 Feet when exterior of structure must not exceed the distance shown in the shaded region shown to the right. \_ 20 Feet Venting into this shaded area may require restrictor adjustments. See the \_ 15 Feet section "Restrictor Adjustment" for details. \_ 10 Feet NOTE: To achieve optimum performance, we recommend keeping the vent as short as possible (horizontal run especially). 0 Feet

5 Feet

#### Pellet Vent Type

Must be 4" diameter Type "L" (except for masonry fireplace installations) - or - connect the vent to a factory built type "A" chimney. All vent joints (including adapters, elbows, etc...) must be sealed with 500° F. RTV silicone.

#### Installing the Pellet Vent




Seal each vent section (including adapters, elbows, etc...) by injecting a liberal amount of 500° F. RTV silicone into the gap between sections.

- Horizontal sections must have a 1/4" rise every 12" of travel.
- Pellet vent connections must be sealed airtight with 500° F. RTV silicone and screwed together with at least three sheet metal screws.

#### **Pellet Vent Termination**

- Vent must terminate on the exterior of the dwelling. Horizontal terminations must protrude a minimum12" from the wall. Vertical terminations must protrude a minimum 24" from the roof surface. In addition, all clearances listed below must be met.
- Must have an approved cap (to prevent water from entering) or a 45° downturn with rodent screen.
- If the termination is located on a windy side of the house, an approved house shield is recommended to prevent soot from building up on the side of the house.
- Must not be located where it will become plugged by snow or other material.



- Minimum 4' clearance below or beside any door or window that opens Α
  - (This clearance may be reduced to 18" if using outside air (see page 11) we recommend the door or window be kept closed during operation.
    - Minimum 1' clearance below or beside any window that does not open.
- Minimum 1' clearance above any door or window that opens В
- Minimum 2' clearance from any adjacent building С
- Minimum 7' clearance above any grade when adjacent to public walkways D
  - NOTE: Vent may not terminate in covered walkway or breezeway.
- Minimum 2' clearance above any grass, plants, or other combustible materials Ε
- Minimum 3' clearance from any forced air intake of any other appliance F
- Minimum 2' clearance below eaves or overhands G
- Н Minimum 1' clearance horizontally from combustible wall
- Must be a minimum of 2' above the roof Χ

#### Mobile Home Requirements

- Outside air is required (used for combustion) - see the directions below.
- The heater must be bolted to the floor (Some states do not require this; check with your local building department). See the illustration to the right.
- The heater must be grounded to the steel chassis of the mobile home (Some states do not require this; check with your local building department).


WARNING: DO NOT INSTALL IN

SLEEPING ROOM.

CAUTION: THE STRUCTURAL

INTEGRITY OF THE MANUFACTURED HOME FLOOR, WALL, AND CEILING/ROOF MUST BE

MAINTAINED.




#### Outside Air (used for combustion)

Must not be drawn from an enclosed space (garage, unventilated crawl space).

HINT: Travis Industries strongly suggests outside air for all residential installations, especially for those that are energy efficient, air-tight homes.

- Must not be over 15' long.
- Must be made with 1 3/4"
   diameter or larger metal or
   aluminum duct with a metal
   screen attached to the end
   to keep out rodents
   (P.V.C. or other
   combustible materials may
   not be used). We
   recommend the Travis
   Industries Outside Air Kit
   (part # 99200136).
- Must not terminate above or within 1' of the chimney termination.
- Must have a rain cap or down-turned elbow to prevent water from entering.
- Must be located so that it will not become plugged by snow or other material.



#### Alcove Installation Requirements

When the pellet stove is placed in a location where the ceiling height is less than 7' tall, it is considered an alcove installation. Because of the reduced height, the requirements listed below must be met.

- Minimum height is 60"
- Minimum width is 46"
- Maximum depth is 48"
- Minimum clearance of 9" on each side and 3" on back

#### Baffle Installation

Install the baffles included with the stove (see page 29 for details).

#### Door Seal Verification

The door is aligned prior to leaving the factory. However, shipping and installation may cause the door to become mis-aligned. Verify the door is correctly aligned and seals properly (see the section "Door Seal" under Yearly Maintenance).

#### Restrictor Adjustment

The restrictor is used to adjust airflow to the firepot. It should be adjusted to match the heat output setting and burn the pellets at the appropriate rate. This keeps the firepot as clean as possible.

**For low heat output settings** the restrictor will need to be closed or near closed to limit the amount of air. This prevents the stove from burning the pellet fuel faster than it is fed.

For medium heat output settings the restrictor will need to be opened to a medium position.

**For high heat output settings** the restrictor will need to be opened to a high position. This prevents the firepot from over-filling with pellets and becoming clogged with ash clumps.


Keeping your firepot clean is the most important step to maintaining a safe and efficient stove. Check and clean your firepot daily until you find the correct restrictor settings and appropriate firepot cleaning interval.

#### Not Enough Air

If clinkers (ashes that solidify into a clump) develop or the flame appears lazy and slow to blow the ash out of the firepot, pull the restrictor outward until the flame becomes active and the firepot holes remain clean. NOTE: If the restrictor is fully out, yet the firepot does not remain clean, the stove needs to be cleaned and checked for air leaks (see "Maintenance" section of this manual).

#### **Too Much Air**

If the flames are too active (small, flickering flames) or if burning pellets are expelled from the firepot, move the restrictor rod inwards until the flame slows down and no burning pellets are expelled (note: it is okay to have "glowing embers" jump out of the firepot). Another symptom of too much air is the heater "blowing the fire out" – a condition in which the pellets burn faster than they are fed (this is most common on low).




#### Thermostat Installation

! Do not connect 120 VAC to the thermostat circuit of this heater (do not use a household thermostat used for a wall-board or other electical heater).


A thermostat is included with this heater (part # 99300650). Follow the directions below to install.


1 Attach the thermostat wire to the circuit board (see the illustration below). Route the wire through the back of the heater (away from any hot or moving components).




Attach the quick-connects to the two posts near the molex connector on the circuit board (orientation does not mater).


- 2 Determine a location for the thermostat that is within range of the 20' length of thermostat wire. It should be centralized in the room and away from the heater. The wire may be routed externally on the wall or behind the wall (preferred).
- 3 Follow the directions to the right to attach the thermostat and thermostat wires.








## Installation Example: Direct "Through-the-wall" Installation




## Installation Example: Interior Vertical Installation




\* Install vent at clearance specified by the vent manufacturer.

#### Installation Example: Class A Chimney Retrofit




Install vent at clearance specified by the vent manufacturer.

#### Installation Example: Masonry Fireplace Hearth Stove




#### Installation Example: Zero-Clearance (Metal) Fireplace Hearth Stove



NOTE: you will probably need a short horizontal section here to clear the lintel and allow the hopper lid to open.

© Travis Industries 100-01154 4080725

## Installation Example: Freestanding Masonry Chimney




\* Install vent at clearance specified by the vent manufacturer.

#### Safety Notice

Read this entire manual (especially the "Safety Precautions" on pages 4 and 5) before using this stove. Failure to follow the instructions may result in property damage, bodily injury, or even death.

- ! Do not unplug the stove to turn it off. This stove relies upon electricity to push the flue gases out the pellet vent unplugging it may lead to smoke entering your room.
- ! Failure to maintain your heater will lead to a restricted combustion air system, leading to poor performance and in some cases, smoke spillage into the room. See the "Maintenance" section for details.

#### Location of Controls




#### Starting the Heater for the First Time

#### Start the Heater - Let it Burn for 1 Hour - THEN OPEN THE DOOR

The stove paint is cured through heat. To prevent it from bonding to the door gasket, you must burn the heater for approximately 1 hour, then open and close the door to break any bonding.

#### **Curing the Paint**

This stove uses a heat-activated paint that will emit some fumes while starting the first fire. Open doors and windows to the room to vent these fumes. You may also notice oil burning off of the interior of the stove. This rust-stopping agent will soon dissipate.




#### Priming the Auger

Because of its electronic control panel, this stove does not require priming. If you run out of pellets you may notice it will take approximately 5 minutes longer for the stove to start.

#### Loading Pellets

Lift the hopper lid to its vertical position. Pour pellets into the hopper until full. NOTE: The hopper holds approximately 115 pounds of pellets.



#### The Two Modes of Operation

#### Manual


Manual mode requires the user to turn the heater on and off manually.

#### Auto (requires a thermostat)

Auto mode allows you to use a thermostat to control room temperature. The stove automatically turns on when the temperature drops below the thermostat setting. Once the stove reaches operating temperature, the stove then runs at the heat output setting selected.

# Switching Modes While in Operation

Whenever the stove is switched from one mode to another while in operation, the stove will enter the "start-up" sequence for a minimum of 20 minutes.



#### Manual Mode

Manual mode requires the user to turn the heater on and off manually.


#### To Start


Press the "Manual Start" button. That's it. The stove automatically goes to a medium burn rate and high fan while the igniter starts the fire burning within 10 minutes. During this period the lowest "HEAT OUTPUT" light will flash. If the stove does not start in 30 minutes, the stove turns off.

Once up to temperature, the stove will then run at the heat output setting selected on the control panel (see "To Adjust the Heat" below).

#### To Shut Down

Move the mode switch to "OFF". The exhaust blower will still run until the heater cools down.






#### To Adjust the Heat

Press the "Heat" buttons to adjust the heat output.

NOTE: During start-up you may adjust the heat setting. This heat setting will take affect once the start-up sequence is complete.




#### Auto Mode

Auto mode allows you to use a thermostat to control room temperature. The stove automatically turns on when the temperature drops below the thermostat setting. Once the stove reaches operating temperature, the stove then runs at the heat output setting selected.

#### To Adjust Room Temperature (or Start the Stove)

Move the thermostat to the heat setting desired. If the room is cooler than the setting, the stove will go through the start-up sequence for approximately 10 minutes. During this period the lowest "HEAT OUTPUT" light will flash. Once up to temperature, the stove will then run at the heat output setting selected on the control panel. If the room is too hot, move the thermostat to a lesser setting.



#### To Adjust the Heat

Press the "Heat" buttons to adjust the heat output.

#### HINT:


If you find that the stove turns on and off repeatedly, you may wish to turn the heat output to a lesser setting. The lower setting will provide a more consistent heat output over time, eliminating the need for the thermostat to repeatedly turn the stove off.


#### NOTE:

If the thermostat calls for heat while the stove is still cooling down, the stove will go through the start-up sequence (for a minimum of 20 minutes).

#### To Shut Down

Move the mode switch to "OFF". The exhaust blower will still run until the heater cools down.





## **Operation**

#### Restrictor Adjustment

The restrictor is used to adjust airflow to the firepot. It should be adjusted to match the heat output setting and burn the pellets at the appropriate rate. This keeps the firepot as clean as possible.

**For low heat output settings** the restrictor will need to be closed or near closed to limit the amount of air. This prevents the stove from burning the pellet fuel faster than it is fed.


For medium heat output settings the restrictor will need to be opened to a medium position.

**For high heat output settings** the restrictor will need to be opened to a high position. This prevents the firepot from over-filling with pellets and becoming clogged with ash clumps.

Keeping your firepot clean is the most important step to maintaining a safe and efficient stove. Check and clean your firepot daily until you find the correct restrictor settings and appropriate firepot cleaning interval.

#### Not Enough Air


If clinkers (ashes that solidify into a clump) develop or the flame appears lazy and slow to blow the ash out of the firepot, pull the restrictor outward until the flame becomes active and the firepot holes remain clean. NOTE: If the restrictor is fully out, yet the firepot does not remain clean, the stove needs to be cleaned and checked for air leaks (see "Maintenance" section of this manual).



#### Too Much Air

If the flames are too active (small, flickering flames) or if burning pellets are expelled from the firepot, move the restrictor rod inwards until the flame slows down and no burning pellets are expelled (note: it is okay to have "glowing embers" jump out of the firepot). Another symptom of too much air is the heater "blowing the fire out" – a condition in which the pellets burn faster than they are fed (this is most common on low).

#### Adjusting the Fan Speed



# **Operation**

#### Start-Up Sequence

This stove utilizes a start-up sequence whenever the mode switch is changed or the heater is started when cold. This is to ensure proper operation through all possible settings and operational states (hot or cold, pellets burning or not burning, etc.). This sequence over-rides all user settings (except the "OFF" position) to set the auger feed rate to medium, the exhaust blower to high, and the igniter on. During this period the lowest "HEAT OUTPUT" light will flash.


#### "AUGER ON" Light

This light comes on when the auger is turning. This allows the operator to determine when the auger is turning.

#### "MAINTENANCE REQUIRED" Light

**NOTE**: If the "MAINTENACE REQUIRED" light comes on, check the items below **before calling for service**.

The "MAINTENACE REQUIRED" light is used to indicate maintenance is required on the heater. It will turn on due to various operating circumstances. When it turns on, a second light will turn on near "HEAT OUTPUT" (see the illustration to the right). Determine the maintenance code (2, 4, or 6), then use the chart below to diagnose and remedy the situation.



	T		
<u>Light</u>	<u>Likely Cause</u>	Remedy	
2	Heavy Ash Build-Up in Exhaust Duct	Clean the Firebox (see page 34)	
(green)	Heavy Ash Build-Up in Exhaust Housing or Plugged Tubing	Clean the Exhaust Housing and Tubing (see page 35)	
	Heavy Ash Build-Up in Vent	Clean the Vent (see page 35)	
4	Heater Ran Out of Pellets	Refill the Hopper (see page 21)	
(yellow)	Heater Did Not Start-Up Correctly	Re-Start the Heater and Verify the Pellets Ignite after 10 Minutes	
	Power Outage	Re-Start the Heater (see page 26)	
	Restrictor Not Set Properly	Re-Start the Heater and Monitor Restrictor Setting (see page 24)	
	Burnpot Clogged	Clean Burnpot (see page 28)	
	Air Leak	Verify Door, Glass, and Ashpan Seal Correctly (see page 37)	
	Heavy Ash Build-Up	Clean the Firebox (see page 34), Exhaust Housing (see page 35), and Vent (see page 35)	
6 (red)	Electrical Input Error (voltage or mhz fluctuation, amp deficiency, etc.)	Unplug the Heater then Plug it Back In (this restarts the circuit board)	
	Components Over-Heated	Clean the Heater and Vent (a plugged heater will slow exhaust flow, increasing temperatures – see pages 34- 35)	
	Faulty Wiring / System Fault	If this Fault Persists, Contact Your Dealer	

## **Operation**

#### "MANUAL AUGER" Button


This button turns the auger on. It is used to "prime" the auger after the hopper has run out of pellets.

#### Power Outages

If a sustained power outage occurs while in "Manual", the stove will go to a "cool down" mode to vacate smoke once power returns. If the power outage was short, the heater will go to the start-up sequence. If in "Auto", the stove will re-start (if the room is cool).

! Because this stove relies upon a blower to evacuate the smoke, some smoke may enter the home during a power outage. To keep to a minimum, leave the door closed.





#### Using a Pellet/Corn Mix with This Heater

This heater may burn a mixture of corn and wood pellets up to a 50% - 50% proportion by volume. Shelled corn burned in Travis pellet appliances must be clean (free of husk and cob residue) and have a moisture content no greater than 15%.

# DO NOT BURN A MIX WITH MORE THAN 50% CORN TO WOOD PELLETS. THOROUGHLY MIX THE TWO FUELS TOGETHER TO BE SURE OF AN EVEN BURN RATE.

- If combustion is slow, if the fire is slow to start, or if clinkers (ashes that solidify into a clump) build up rapidly in the fire pot, decrease the proportion of corn and increase the proportion of wood pellets until you find a proportion that works well in your appliance.
- If your stove or insert is operated with a thermostat, you may notice the automatic igniter at times fails to light a 50/50 corn to pellet mix. If you experience this, decrease the proportion of corn and increase the proportion of wood pellets in the mix.

For an optimum fire and greatest efficiency, it is important to keep the fire pot free of built up ashes. If you are burning only high quality wood pellets, you should check and clean the fire pot at least every two weeks or after ten bags of pellets.


If the pellets you are burning have a high ash content or if you burn a corn/wood pellet mixture, we recommend that you check the fire pot every day and clean it if necessary.

#### Daily Maintenance (whenever using the stove)

#### Inspect the Burn

When burning on high, the flames should be bright orange with embers jumping from the firepot.

NOTE: the optimal restrictor position will vary over time as soot builds up inside the exhaust system. See "Restrictor Adjustment" for details.




# Make Sure Pellets are Not Piling Up

If the pellets pile up over the burn pot, turn the mode switch to "OFF".

The most likely causes are:

- Restrictor needs adjustment (see "Restrictor Adjustment" in the installation section of this manual)
- The door, glass, or ashpan is open or has an air leak
- The firepot requires cleaning
- The exhaust system requires cleaning




#### Daily Maintenance (whenever using the stove) - Continued

# Check Firepot for Clinkers

If the flames seem to be coming only from the sides, or are orange/black, turn the heater off and check for clinkers (ashes that solidify into a clump).

The most likely causes are:

- Restrictor needs adjustment (see "Restrictor Adjustment" in the installation section of this manual)
- Poor pellet quality
- The door or glass has an air leak
- The exhaust system requires cleaning




#### Cleaning the Firepot

#### **WARNING:**

Make sure the heater has fully cooled (approximately 25 minutes) before opening the door and conducting service.

To clean the firepot, open the door (see page 27) and knock away any debris on the firepot with a screwdriver. If severely clogged, remove the firepot to gain better access.




## Daily Maintenance (whenever using the stove) - Continued

#### **Door Opening**

#### **WARNING**:

Make sure the heater has fully cooled (approximately 25 minutes) before opening the door and conducting service.



#### Weekly Maintenance (or every 5 bags of pellets)

#### Flyash Removal

This heater was designed to allow for easy flyash removal with the included tools. However, to ease maintenance, several pellet stove owners have purchased vacuums specifically made to remove flyash. Furthermore, some of these vacuums are heat-resistant to allow for flyash removal while it is still warm. **Do not use a standard vacuum on this appliance** (except to clean the pellet dust out of the hopper). Standard vacuums may spread the fine particles inside the flyash into the home and are not heat-resistant (hot flyash may cause the internal portion of vacuums to ignite).






#### Clean the Hopper

Run the stove until the pellets run out. Open the hopper and remove the dust and debris near the bottom of the hopper.

#### Clean the Heat Exchange Tubes



#### Weekly Maintenance (or every 5 bags of pellets) - continued

#### Cleaning the Optional Gold Surfaces (Door and optional Grill)

Fingerprints or other marks left on gold surfaces may become etched in place if they are not wiped clean prior to turning the stove on. Clean the gold with denatured alcohol and a soft cloth (make sure the heater is cool). Other cleaners may leave a film that may become etched into the gold.


#### Clean the Baffles


**WARNING**: Make sure the heater has fully cooled (approximately 25 minutes) before conducting service.

Use both hands to lift each baffle up and forward. Then tilt the baffle downward to remove any flyash that may have accumulated on top of the baffle.

**NOTE**: you do not need to remove the baffle from the firebox.

The firebox baffles install on ledges at the top of the firebox. The two tabs (at the outside back corners) insert into notches at the right and left rear corners of the firebox walls.





© Travis Industries 4080725 100-01154


## Weekly Maintenance (or every 5 bags of pellets) - continued


#### Sweep Ash Into Ashpan

#### **WARNING:**


The firebox becomes very hot during operation. Let the stove cool completely before conducting service.

(a) Swing the side ash trap door up.







Brush all flyash into the ash dumps, including the flyash inside the firepot holder.




Lift it up and away from the firebox. Repeat for the opposite side.



Slide the ash pan trap door forward to expose the ash dumps (the door can be removed and cleaned if necessary)



Replace the ash trap doors and firepot. Slide the ash pan trap door forward.




#### Weekly Maintenance (or every 5 bags of pellets) - continued

#### Check Ashpan, Dispose if necessary

**WARNING**: Make sure the heater has fully cooled (approximately 25 minutes) before conducting service.

**WARNING**: The ashpan must be in place while the heater is in use.



#### NOTE:

When replacing the ash pan make sure it is pushed all the way in.

**Disposal of Ashes** – Ashes should be placed in a metal container with a tight fitting lid. The closed container of ashes should be placed on a noncombustible floor or on the ground, well away from all combustible materials, pending final disposal. If the ashes are disposed of by burial in soil or otherwise locally dispersed, they should be retained in the closed container until all cinders have been thoroughly cooled.

#### Clean the Glass

Open the doors and clean the glass with a non-abrasive glass cleaner and rag.

© Travis Industries 4080725 100-01154


#### Yearly Maintenance (or every ton)

The following section details extensive maintenance procedures. We strongly suggest these items be carried out by a trained service technician, possibly by a service agreement set up with your dealer.

WARNING: Disconnect the power cord and make sure the heater has fully cooled prior to conducting service.

**Soot and Flyash: Formation and Need for Removal** – The products of combustion will contain small particles of flyash. The flyash will collect in the exhaust venting system and restrict the flow of the flue gases. Incomplete combustion, such as occurs during startup, shutdown, or incorrect operation of the room heater will lead to some soot formation which will collect in the exhaust venting system. The exhaust venting system should be inspected at least once every year to determine if cleaning is necessary.


#### Clean the Vertical Exhaust Duct




Clean the Exhaust Duct (the stove must be cool and unplugged)

# Clean the Convection Blower


(the stove must be cool and unplugged)




The convection blower inlet can be vacuumed out (if needed). If extensive cleaning is needed, it can be removed for cleaning.



#### Clean the Exhaust Blower



#### Clean the Vent



Warning: Whenever any portion of the pellet vent is disconnected, the joints must be sealed with RTV 500° F. silicone sealant.

© Travis Industries 4080725 100-01154

#### **Door Seal**

**Door Alignment** 


- ! Air leaks into the firebox will decrease the stove's performance greatly, leading to excessive sooting, inefficient burning, and perhaps a malfunction.
- The door gasket must contact the entire perimeter of the door and create an airtight seal. To verify this, open the door, hold a dollar bill against the body of the heater, close the door, and secure the latch. The dollar bill should be held firmly in place (check the entire perimeter of the door. If it is loose or falls out, the door must be adjusted (see the following page).

Because the door is three-sided, it is

crucial the door is aligned correctly. We recommend that you open the


hopper lid and look down upon the door and body of the heater. Use the illustration to the right to determine

the correct door alignment.




#### **Correctly Aligned Door**

When properly adjusted, the door should be evenly spaced from the front of the stove (and shut tight, compressing the gasket).




Note how both corners are evenly spaced.

<u>Latch Too Tight</u> - In the illustration below, the latch is too tight (this is the most common misalignment). Loosen the latch and tighten the hinge.



Note how the gasket separates from the body.

<u>Hinge Too Tight</u> - In the illustration below, the hinge is too tight. Loosen the hinge and tighten the latch.




Note how the gasket separates from the body.

100-01154


#### Adjusting the Door Hinge and Latch

• The door hinge and door latches may be adjusted to pull the door closer to the body. The illustration below details how to adjust these components. NOTE: Make sure to read the section "Door Alignment" on the previous page before adjusting the door.



#### Check for Air Leaks Around the Door, Glass, and Ashpan

- ! Air leaks into the firebox will decrease the stove's performance greatly, leading to excessive sooting, inefficient burning, and perhaps a malfunction.
- Inspect the door gasket to make sure it is fully attached. Use stove gasket cement to re-attach if necessary. If the door gasket is worn or flattened, replace.
- If the glass is cracked, replace. The glass is held in place by glass clips. See the illustration below for details.
- Remove the ashpan and inspect the gasket around the perimeter of the ashpan. Re-attach, or replace the gasket if necessary.




#### Replacement Parts

ASH DUMP PLATE, LARGE PS/PI	91002022	GASKET, DOOR 7/8" x 85" WHITE ROPE	99900431
ASHTRAP DOORS	93005054	GASKET, GLASS 5/8"x137" BLACK	99900398
AUGER BEARING PLT, LOWER, LRG	91002024	GLASS, FRONT, P12/14, P13	91002004
AUGER BUSHING PLATE, UPPER	93005093	GLASS, SIDE, P12/14, P13	91002005
AUGER DRIVE COLLAR, 1997 & UP	91002021	GROMMET, IGNITOR WIRE BLACK RUBBER	100-02811
AUGER FLIGHT INSPECTION COVER	210-02702	GSKT, CLEAN-OUT CVR, 3.250 x 2.750	100-03235
AUGER FLIGHT, 2000+ LRG PEL	91002013	GSKT, COMB BLOWER (BODY)	100-03206
AUGER MOTOR STOP, P11-P15	93005096	GSKT, COMB BLOWER(MOTOR) 7" dia	100-03231
AUGER MOTOR, ALL PS/PI	90-0191	GSKT, EXHAUST PLATE 4.25"x4.25"	100-03230
AUGER SUB-ASS'Y - LARGE PEL	91002020	HANDLE, HOPPER LID	100-04312
BLOWER, COMB, PELLET	93005535	HANDLE, PEL CNTRL BOARD 97	99300094
BLOWER, CONV, P2-8/11-15/G1	98900755	HINGE PLATE ASS'Y	91002017
BRUSH, BROOM STYLE - PELLET	100-04301	HOSE NIPPLE, BARBED	100-04307
BURNPOT ASSY, FIREPOT	99300171	IGNITER, LG PS/PI	99300149
CABLE HANGER CLIP	100-04310	KNOB (PHENOLIC), 3/4" dia	100-04241
CNTRL BRD, LG PEL (P13-15)	100-00203	LBL, EXHAUST DAMPER	112-00505
CORD RESTRAINER	100-00112	MAGNET w/OUT SHEATH 1x.75" 1/4" THICK	100-02801
DAMPER PLATE S-ASS'Y - LRG PS	221-22089	OIL PAN, COMB BLOWER - LG PEL	210-03216
DRAFT (FLOW) SWITCH	93005060	POWER CORD, PS/PI	93005015
DRAFT FLOW TUBING	99300164	REFRACTORY SIDE CLIP, LEFT	210-03831L
FIRE-BACK, CAST IRON,	93005059	REFRACTORY SIDE CLIP, RIGHT	210-03831R
FIREBOX BAFFLE, LEFT	210-05199	SCRAPER ROD (P12/13/14)	211-01660
FIREBOX BAFFLE, RIGHT	210-05198	SNAP-DISC - 120deg CERAMIC NO	100-00232
FUSE HOLDER (IN-LINE)	100-00210	SNAP-DISC - 120deg NO # NO	100-00231
FUSE, 5AMP, 5 - FOR INLINE	93-0695	SNAP-DISC - 200deg NC # NC	100-00233
FUSE, 6AMP, 5 - CONTROL BOARD	93005019	TOOL, GLASS LATCH/RESTRICTOR	100-02302
GASKET CEMENT (WHITE), 4oz.	99900409	WIRE HRNS, PEL, JUMPER, LRGPELLET	100-00390
GASKET, ASHPAN 70" BLK 1/2"x1/8" ADH	99900428	WIRE HRNS, PEL, PS/PI 97 & UPLARGE OR SMALL	100-00391

#### **Exhaust Blower**

This blower may create a low-pitched hum. This sound will change as the HEAT OUTPUT is altered.



Convection Fan
The modern high efficiency
fan may produce a low
hum, particularly on
"HIGH". This sound will
change as the FAN setting is changed.

#### WARNING - DO NOT REMOVE OR COVER THIS LABEL



**Listed Pelletized** Solid Fuel Burning Appliance Also for Use in Mobile Homes Model: Astoria PS

Serial No:



Tested to: ASTM E, 1509-95, Room Heater Pellet Burning Type (UM) 84 HUD

Electrical Rating: 115V, 60Hz, 3 Amp; Start 3 Amps, Run 1.5 Amps

Maximum Input Rating: 5.5 lbs (2.5kg)/hr

This pellet fired appliance has been tested and listed for use in manufactured (mobile) homes in accordance with OAR 814-23-900 through 814-23-909.

WARNING - FOR MANUFACTURED HOMES: Do not install appliance in a sleeping room. Must utilize outside combustion air inlet (part #99200136) or equivalent. Structural integrity of the manufactured home floor, ceiling, and walls must be maintained.


Install only in accordance with the manufacturer's installation and operating instructions. Contact local building or fire officials about restrictions and installation inspection in your area.


Use only listed 4 in /100 mm diameter listed type "L" or "PL" venting system. See manufacturer's installation instructions and local codes for precautions required for passing chimney through a combustible wall or ceiling. Do not connect this appliance to a vent serving another appliance. Inspect and clean exhaust venting system frequently in accordance with manufacturer's instructions.

May be installed in a sleeping room with use of outside combustion air inlet (Part #99200136) or equivalent.

Minimum Clearance to Combustible Materials (Measured to Stove Top)

		Interior Vertical Flue Installation	Horizontal Through the Wall Installation
Left Sidewall	Α	9″	9″
Right Sidewall	В	9″	9″
Backwall	С	**	3″
Corner	D	3″	3″
Flue Vent	Ε	3″	3″





Maximum alcove depth 48 in/1220 mm, minimum ceiling height 60 in/1525 mm, minimum alcove width 46 in/1165 mm.

Combustible floor must be protected by a non-combustible material, extending to the front (G) 6 in/150 mm and to the sides (H) 0 in/0 mm.

EXCEPTIONS: Non-combustible floor protection must extend beneath a vent tee when installed.

\*\* This dimension will vary depending on brand of listed type "L" vent. See manual for details.

For use with 1/4 in/6 mm to 5/16 in/7 mm diameter pelletized wood fuels only.

Replace glass only with 5 mm ceramic glass available from your dealer.

DANGER: Risk of electrical shock. Disconnect power supply before servicing. Route power cord away from unit. Do not route power cord beneath heater.

Operate only with viewing door and ash removal tray tightly closed. Do not obstruct combustion air openings. The space beneath heater must not be obstructed. Keep all furnishings away from heater.

Mfg. by TRAVIS INDUSTRIES, INC. 10850 117th PI N.E. Kirkland, WA 98033



#### U.S. ENVIRONMENTAL PROTECTION AGENCY

This model is exempt from EPA certification under 40 CFR 60.531 by definition [Wood Heater (A) "Air-to-fuel Ratio"].

Date of Manufacture



To register your TRAVIS INDUSTRIES, INC. 7 Year Warranty, complete the enclosed warranty card and mail it within **ten (10)** days of the appliance purchase date to: TRAVIS INDUSTRIES, INC., 4800 Harbour Pointe Blvd. SW, Mukilteo, WA 98275. TRAVIS INDUSTRIES, INC. warrants this appliance (appliance is defined as the equipment manufactured by Travis Industries, Inc.) to be defect-free in material and workmanship to the original purchaser from the date of purchase as follows:

Check with your dealer in advance for any costs to you when arranging a warranty call. Mileage or service charges are not covered by this warranty. This charge can vary from store to store.

#### Years 1 & 2 - COVERAGE: PARTS & LABOR

Firebox Assembly:

Firepot, Firepot Holder, Ash Cleanout Doors, Ashbox or Ash Dump, Cast Fireback, Heat Exchanger Tubes, Exhaust Manifold, Exhaust Box

Door Assembly:

Door Frame, Latch Assembly, Glass Retainers

Auger Assembly

Auger Flight, Auger Tube, Auger Bushings

**Exclusions:** 

Paint, Gasketing

Ceramic Glass

Glass (breakage from thermal shock)

Igniter System Igniter, Igniter Leads

**Electrical System** Auger Motor, Convection Blower, Exhaust Blower, Circuit Board, Snap Disks, Wiring Harness, Vacuum Switch

Cast Iron Parts

Warranted against breakage, cracking, or burn through

<u>Accessories</u>

Ceramic Log with Log Shelf, Remote

Re-Installation Allowance

In cases where heater must be removed from home for repairs, a partial cost of re-installation is covered (pre-authorization required)

One-Way Freight Allowance

One-way freight allowance on pre-authorized repair done at factory is covered.

#### Years 3 Through 5 - COVERAGE: PARTS & LABOR

Firebox Assembly:

Firepot, Firepot Holder, Ash Cleanout Doors, Ashbox or Ash Dump, Cast Fireback, Heat Exchanger Tubes, Exhaust Manifold, Exhaust Box

**Door Assembly:** 

Door Frame, Latch Assembly, Glass Retainers

Auger Assembly

Auger Flight, Auger Tube, Auger Bushings

One-Way Freight Allowance

One-way freight allowance on pre-authorized repair done at factory is covered.

Exclusions: Paint, Gasketing, Ceramic Glass, Igniter System, Electrical System, Cast Iron Parts, Accessories, Re-Installation Allowance

#### Years 6 & 7 - COVERAGE: PARTS ONLY

Firebox Assembly:

Door Assembly:

Firepot, Firepot Holder, Ash Cleanout Doors, Ashbox or Ash Dump, Cast Fireback, Heat Exchanger Tubes, Exhaust Manifold, Exhaust Box

Door Frame, Latch Assembly, Glass Retainers

**Exclusions:** 

Paint, Gasketing, Ceramic Glass, Igniter System, Electrical System, Cast Iron Parts, Accessories, Auger Assembly, Re-Installation

Allowance, One-Way Freight Allowance, Labor

#### **CONDITIONS & EXCLUSIONS**

This new appliance must be installed by a qualified installer. It must be installed, operated, and maintained at all times in accordance with the instructions in the Owner's Manual. Any alteration, willful abuse, accident, neglect, or misuse of the product shall nullify this warranty.

This warranty is nontransferable, and is made to the ORIGINAL purchaser, provided that the purchase was made through an authorized Travis dealer.

2. 3.

- Discoloration and some minor expansion, contraction, or movement of certain parts and resulting noise, is normal and not a defect and, therefore, not covered under warranty.
- The warranty, as outlined within this document, does not apply to the chimney components or other Non-Travis accessories used in conjunction with the installation of this product. If in doubt as to the extent of this warranty, contact your authorized Travis retailer before installation.

  Travis Industries will not be responsible for inadequate performance caused by environmental conditions such as nearby trees, buildings, roof tops, wind, hills 4.
- 5. or mountains or negative pressure or other influences from mechanical systems such as furnaces, fans, clothes dryers, etc.

6.

- This Warranty is void if:

  a. The unit has been operated in atmospheres contaminated by chlorine, fluorine or other damaging chemicals
- b. The unit is subject to submersion in water or prolonged periods of dampness or condensation
- c. Any damage to the unit, combustion chamber, heat exchanger or other components due to water, or weather damage which is the result of, but not limited to, improper chimney/venting installation.

  Exclusions to this 7 Year Warranty include: injury, loss of use, damage, failure to function due to accident, negligence, misuse, improper installation, alteration or adjustment of the manufacturer's settings of components, lack of proper and regular maintenance, damage incurred while the appliance is in transit, alteration, or act of God. 7.
- This 7 Year warranty excludes damage caused by normal wear and tear, such as paint discoloration or chipping, worn or torn gasketing, chipped or cracked firebrick, etc. Also excluded is damage to the unit caused by abuse, improper installation, modification of the unit, or the use of fuel other than that for which the unit is configured. 8.
- Damage to gold or nickel surfaces caused by fingerprints, scratches, melted items, or other external sources left on the gold or nickel from the use of cleaners other than denatured alcohol is not covered in this warranty.

  TRAVIS INDUSTRIES, INC. is free of liability for any damages caused by the appliance, as well as inconvenience expenses and materials. Incidental or consequential damages are not covered by this warranty. In some states, the exclusion of incidental or consequential damage may not apply. This warranty does not cover any loss or damage incurred by the use or removal of any component or apparatus to or from the Travis appliance without the express written permission of TRAVIS INDUSTRIES, INC. and bearing a TRAVIS INDUSTRIES, INC. label of approval. 9.
- 10 11.
- 12 Any statement or representation of Travis products and their performance contained in Travis advertising, packaging literature, or printed material is not part of
- this 7 year warranty. 13.
- This warranty is automatically voided if the appliance's serial number has been removed or altered in any way. If the appliance is used for commercial purposes, it is excluded from this warranty.

  No dealer, distributor, or similar person has the authority to represent or warrant Travis products beyond the terms contained within this warranty. TRAVIS 14.
- 15
- INDUSTRIES, INC. assumes no liability for such warranties or representations.

  Travis Industries will not cover the cost of the removal or re-installation of hearths, facing, mantels, venting or other components.

  If for any reason any section of this warranty is declared invalid, the balance of the warranty remains in effect and all other clauses shall remain in effect.
- This 7 year warranty is the only warranty supplied by Travis Industries, Inc., the manufacturer of the appliance. All other warranties, whether express or implied, are hereby expressly disclaimed and purchaser's recourse is expressly limited to the warranties set forth herein.

#### **WARRANTY SERVICE IS NEEDED:**

- If you discover a problem that you believe is covered by this warranty, you MUST REPORT it to your Travis dealer WITHIN 30 DAYS, giving them proof of purchase, the purchase date, and the 1. model name and serial number
- model name and serial number.

  Travis Industries has the option of either repairing or replacing the defective component.

  If your dealer is unable to repair your appliance's defect, he may process a warranty claim through TRAVIS INDUSTRIES, INC., including the name of the dealership where you purchased the appliance, a copy of your receipt showing the date of the appliance's purchase, and the serial number on your appliance. At that time, you may be asked to ship your appliance, freight charges prepaid, to TRAVIS INDUSTRIES, INC. TRAVIS INDUSTRIES, INC., at its option, will repair or replace, free of charge, your appliance if it is found to be defective in material or workmanship within the time frame stated within this 7 year warranty. TRAVIS INDUSTRIES, INC. will return your appliance, freight charges (years 1 to 5) prepaid by TRAVIS INDUSTRIES, INC., to your regional distributor, or dealership.

  Check with your dealer in advance for any costs to you when arranging a warranty call. Mileage or service charges are not covered by this warranty. This charge can vary from store to

"AUGER ON" Light25
"MAINTENANCE REQUIRED" Light25
Alcove Installation Requirements12
Auto Mode23
Baffle Installation12
Before You Begin7
Weekly Maintenance (or every 5 bags of pellets)30
Check Ashpan, Dispose if necessary33
Check Firepot for Clinkers28
Clean the Exhaust Blower35
Clean the Glass33
Clean the Heat Exchange Tubes30
Clean the Hopper30
Clean the Vent35
Clean the Vertical Exhaust Duct34
Cleaning the Firepot28
Clearances - Corner Installation8
Clearances - Straight Installation8
Daily Maintenance (whenever using the stove)27
Dimensions6
Door Seal Verification12
Electrical Specifications6
EPA Compliance6
Floor Protection Requirements7
Flyash Removal30
Fuel6
Heating Specifications6
Important Information2
Inspect the Burn27
Installation Example: Class A Chimney Retrofit16
$In stall at ion Example: \hbox{\it Direct "Through-the-wall" In stall at ion.} \\ 14$
Installation Example: Freestanding Masonry Chimney19
Installation Example: Interior Vertical Installation15
Installation Example: Masonry Fireplace Hearth Stove17
$In stallation  Example: Zero \hbox{-} Clearance  (\hbox{\it Netal})  Fireplace  Hearth  Stove.  .  18$
Installation Options7
Installing the Pellet Vent10
Introduction2

Loading Pellets21
Location of Controls20
"MAINTENANCE REQUIRED" Light25
Make Sure Pellets are Not Piling Up27
Manual Mode22
Maximum Venting Distance9
Mobile Home Requirements11
Normal Operating Sounds39
Outside Air (used for combustion)11
Packing List7
Pellet Vent Termination
Pellet Vent Type10
Planning The Installation7
Power Outages26
Restrictor Adjustment12
Restrictor Adjustment24
Safety Label40
Safety Notice20
Safety Precautions4
Starting the Heater for the First Time20
Start-Up Sequence25
Stove Placement7
Sweep Ash Into Ashpan32
The Two Modes of Operation21
Thermostat Installation13
Venting the Pellet Stove9
Warranty41
Yearly Maintenance (or every ton)34